



## Hardy Rib Snow Rail Installation Guide

1. Use 2" or longer EPDM Rubber washered screws.
2. Install at the line of screws that is between 24" and 30" from the eave of the roof.
3. If purlins are installed under the metal roof, fasten the side closest to the ridge to the purlins. Fasten both sides enough to not deform the steel panels.
4. These snow rails are installed horizontally across the major ribs. (See picture below).
5. Caulk/Sealant may be used where the fasteners are installed but it is not mandatory.
6. These guards can be installed staggered or in a straight line across the roof.
7. Every twelve foot of roof panel should have a line of snow rail for best results.
  - a. Example: If your rake/gable of the roof is 20 ft in length then two rows of guards should be installed. One 24 to 30 inches from the eave and another set, 12 to 13 feet from eave.

